



WIREMOLD
FOR 500 RACEWAY **605 RACEWAY CUTTER**
1. OPEN BLADE AND INSERT TOP OF RACEWAY
FACING PIVOT
2. BRING HANDLE DOWN THROUGH RACEWAY
IN ONE EVEN CUT UNTIL IT BOTTOMS
3. USE PLIERS TO RESHAPE AND DEBURR IF
NECESSARY

