







**WIREMOLD**  
FOR 500 RACEWAY **605 RACEWAY CUTTER**  
1. OPEN BLADE AND INSERT TOP OF RACEWAY  
FACING PIVOT  
2. BRING HANDLE DOWN THROUGH RACEWAY  
IN ONE EVEN CUT UNTIL IT BOTTOMS  
NECESSARY  
3. USE PLIERS TO RESHAPE AND DEBURR IF  
NECESSARY