



BROWSE BY CATEGORIES

HOME ABOUT US CUSTOMER SUPPORT

DEALER LOCATOR

SHOP FOR PARTS

CONTACT US

Search

Site:

Model#:

- [BATH FANS](#)
- [RANGE HOODS](#)
- [CEILING FANS](#)
- [CENTRAL VACUUM SYSTEMS](#)
- [DECORATIVE BACKSPLASHES](#)
- [DOOR CHIMES](#)
- [HEATERS](#)
- [INDOOR AIR QUALITY](#)
- [INTERCOM SYSTEMS](#)
- [IRONING CENTERS](#)
- [MEDICINE CABINETS](#)
- [TRASH COMPACTORS](#)
- [WHOLE HOUSE AUDIO](#)

NuTone NEWS

NuTone® Bath Fan Upgrade Kit - [Just Plug It In!](#)

NuTone Ultra Silent Fan Commercial

➤ [iPod® Docking Station Distributes Music through Music Intercom](#)

➤ [Powerful NuTone® Central Vacuum Provides Deep-Cleaning Power](#)

➤ [Upcoming Events & Trade Shows](#)

➤ [News and Events Archive](#)

RESOURCES

➤ [Product Registration](#)

➤ [Read our FAQs](#)

➤ [Locate a Service Center](#)

Speakers: Music, Door, Intercom Door Speakers



Shown in Antique Brass.

IS-70 Door Speaker without Pushbutton - White

Model IS70WH

- Recessed-Mounted
- Cast metal door speaker without chime pushbutton.
- Mounts beside door.
- White Finish

Installing speakers at your entry doors provides the security and convenience of answering the door from the 'Master' or any remote station/remote control in your home. Many of our door speakers have a built-in door chime pushbutton, so a separate button is not required. Each door speaker includes a 3-1/2" weather resistance speaker for intercom communications. These door speakers are designed to work with NuTone models IM-5000, IMA-4406, IMA-3303, IM-3204 and IMA-516.

Contact your [local dealer](#) for pricing information.

Additional Models Available:

- [IA70](#) IA-70 Surface Mounting Frame
- [IS67D](#) IS-67 Door Speaker with Lighted Pushbutton - Woodgrain/Brass
- [IS67WH](#) IS-67 Door Speaker with Lighted Pushbutton - White
- [IS69AB](#) IS-69 Door Speaker with Lighted Pushbutton - Antique Brass
- [IS69PB](#) IS-69 Door Speaker with Lighted Pushbutton - Polished Brass
- [IS69WH](#) IS-69 Door Speaker with Lighted Pushbutton - White
- [IS70AB](#) IS-70 Door Speaker without Pushbutton - Antique Brass
- [IS70PB](#) IS-70 Door Speaker without Pushbutton - Polished Brass

<p>PARTS ASSISTANT</p> <p>➤ Part # K5509000 Non-Duct Indicating Filter</p> <p>Used on models: LL6200 Series (All) RL6200 Series (Before 2000) SL6200 Series (Before 2000) LL62F (Replacement For This Filter Model Number)</p> <p>➤ Part # 5901A000 Blower Wheel Assembly</p> <p>Used on models: QT80, QT100L Series, QT110, QT9093 Series (Vent Side), VL3668 Series, 671 Series, 672 Series, 8662 Series, 8663 Series, 8664RP, 8672 Series, 8673 Series, 8812, 8814 Series, 8832 Series, 8833</p> <p>➤ Part # 89852000 Grille & Lens Assembly</p> <p>Used on models: 660 Series, 665 Series, 668</p> <p>In U.S.A. Call: 888-336-3948 In Canada Call: 1-905-670-2500 Visit nutone.ca</p>	<p>IS70WHIS-70 Door Speaker without Pushbutton - White ISA63 ISA-63 Door Speaker without Pushbutton ISB64 ISB-64 Door Speaker with Unlighted Pushbutton</p> <p style="text-align: center;">Privacy ©2007 Broan-NuTone LLC</p> <p style="text-align: right;">Technical Support: 888-336-6151 Customer Service: 888-336-3948 Contact us</p>
--	---