

# Automatic Transfer Switches



## Universal (Green) Automatic Transfer Switches


Catalog Number	Description
EGSU100AC	100A Universal N3R with Power Saver Control
EGSU100NSEAC	100A Universal N3R Service Entrance with Power Saver Control
EGSU100L24RAC	100A Universal N3R with Power Saver Control & 24 ckt. Loadcenter
EGSU150NSEAC	150A Universal N3R Service Entrance with Power Saver Control
EGSU200AC	200A Universal N3R with Power Saver Control
EGSU200NSEAC	200A Universal N3R Service Entrance with Power Saver Control
EGSU400NSEAC	400A Universal N3R Service Entrance with Power Saver Control



## Standard Automatic Transfer Switches

Catalog Number	Description
EGS50L12	50A N1 Enclosure
EGS50L12R	50A N3R Enclosure
EGS100	100A N3R Enclosure
EGS100SE	100A N3R Service Entrance
EGS200	200A N3R Enclosure
EGS200SE	200A N3R Service Entrance
EGS100L24R	100A N3R Enclosure & 24 ckt. Loadcenter

# How does the green ATS work?



\* **RTC-100 Controller** is located inside Eaton's Green Line of ATS's.

**Eaton Corporation**  
Electrical Group  
1000 Cherrington Parkway  
Moon Township, PA 15108  
United States  
877-ETN-CARE (877-386-2273)  
Eaton.com

© 2010 Eaton Corporation  
All Rights Reserved  
Printed in USA  
Publication No. TD01605003E  
August 2010



All other trademarks are property of their respective owners.

# Automatic Transfer Switches



## Universal (Green) Automatic Transfer Switches


Catalog Number	Description
EGSU100AC	100A Universal N3R with Power Saver Control
EGSU100NSEAC	100A Universal N3R Service Entrance with Power Saver Control
EGSU100L24RAC	100A Universal N3R with Power Saver Control & 24 ckt. Loadcenter
EGSU150NSEAC	150A Universal N3R Service Entrance with Power Saver Control
EGSU200AC	200A Universal N3R with Power Saver Control
EGSU200NSEAC	200A Universal N3R Service Entrance with Power Saver Control
EGSU400NSEAC	400A Universal N3R Service Entrance with Power Saver Control



## Standard Automatic Transfer Switches

Catalog Number	Description
EGS50L12	50A N1 Enclosure
EGS50L12R	50A N3R Enclosure
EGS100	100A N3R Enclosure
EGS100SE	100A N3R Service Entrance
EGS200	200A N3R Enclosure
EGS200SE	200A N3R Service Entrance
EGS100L24R	100A N3R Enclosure & 24 ckt. Loadcenter

# How does the green ATS work?



\* RTC-100 Controller is located inside Eaton's Green Line of ATS's.

**Eaton Corporation**  
Electrical Group  
1000 Cherrington Parkway  
Moon Township, PA 15108  
United States  
877-ETN-CARE (877-386-2273)  
Eaton.com

© 2010 Eaton Corporation  
All Rights Reserved  
Printed in USA  
Publication No. TD01605003E  
August 2010



All other trademarks are property of their respective owners.