

CONNECTIVITY

Pre-Configured Home Theater Straps

F9004-XX 5.1 Home Theater Strap



F9004-WH

| PART NO. | DESCRIPTION |
|----------|--|
| F9004-BK | Dual decorator straps with binding posts that support a 5.1 home theater solution. |
| F9004-BR | |
| F9004-IV | |
| F9004-LA | |
| F9004-WH | |

WP1010-XX Component Video/Digital Audio Strap



WP1010-WH

| PART NO. | DESCRIPTION |
|-----------|--|
| WP1010-BK | Send component video and 5.1 digital audio over a single Cat 5e cable. |
| WP1010-LA | |
| WP1010-WH | |

F9005-XX 2 Speaker Connection Strap



F9005-WH

| PART NO. | DESCRIPTION |
|----------|--|
| F9005-BK | Decorator strap with binding posts that supports up to two speakers. |
| F9005-BR | |
| F9005-IV | |
| F9005-LA | |
| F9005-WH | |

F9008-XX-V1 5.1 Home Theater Strap with Wall Plate



F9008-WH

| PART NO. | DESCRIPTION |
|-------------|---|
| F9008-DM-V1 | Two decorator straps containing five pairs of binding posts for home theater speaker connection. Includes wall plate. |
| F9008-LA-V1 | |
| F9008-WH-V1 | |


F9006-XX Single Speaker Connection Strap



F9006-WH

| PART NO. | DESCRIPTION |
|----------|---|
| F9006-BK | Decorator strap with binding posts that supports a single speaker connection. |
| F9006-BR | |
| F9006-IV | |
| F9006-LA | |
| F9006-WH | |

WP9009-XX-V1 7.1 Home Theater Wall Plate



WP9009-WH

| PART NO. | DESCRIPTION |
|--------------|--|
| WP9009-DM-V1 | Dual decorator straps with binding posts that support a 7.1 home theater solution. |
| WP9009-LA-V1 | |
| WP9009-WH-V1 | |

WP1014-WH Cable Access Strap



WP1014-WH


| PART NO. | DESCRIPTION |
|-----------|--|
| WP1014-WH | Hides cables behind the wall for a clean look and easy access. |

WP1011-XX HDMI 2-Port Strap



WP1011-WH

| PART NO. | DESCRIPTION |
|-----------|--|
| WP1011-BK | Decorator strap features a High Speed HDMI w/ Ethernet connection and two additional Keystone ports. |
| WP1011-LA | |
| WP1011-WH | |



INSTALLATION AT-A-GLANCE HD CONNECTIVITY FOR FLAT PANELS

1. Install the Cable Access Strap in a single gang box behind the flat panel TV.
2. Install the HDMI 2-Port Strap in a single gang box behind the video source, such as a DVD player.
3. Connect an HDMI cable to the back of the TV.
4. Run the cable through the Cable Access Strap and behind the wall to connect to the back of the HDMI coupler.
4. Run the cable through the Cable Access Strap and behind the wall to connect to the back of the HDMI coupler.
5. Connect an HDMI cable from the video source to the front of the HDMI Strap.

CONNECTIVITY

Pre-Configured Home Theater Straps

F9004-XX 5.1 Home Theater Strap



F9004-WH

| PART NO. | DESCRIPTION |
|----------|--|
| F9004-BK | Dual decorator straps with binding posts that support a 5.1 home theater solution. |
| F9004-BR | |
| F9004-IV | |
| F9004-LA | |
| F9004-WH | |

WP1010-XX Component Video/Digital Audio Strap



WP1010-WH

| PART NO. | DESCRIPTION |
|-----------|--|
| WP1010-BK | Send component video and 5.1 digital audio over a single Cat 5e cable. |
| WP1010-LA | |
| WP1010-WH | |

F9005-XX 2 Speaker Connection Strap



F9005-WH

| PART NO. | DESCRIPTION |
|----------|--|
| F9005-BK | Decorator strap with binding posts that supports up to two speakers. |
| F9005-BR | |
| F9005-IV | |
| F9005-LA | |
| F9005-WH | |

F9008-XX-V1 5.1 Home Theater Strap with Wall Plate



F9008-WH

| PART NO. | DESCRIPTION |
|-------------|---|
| F9008-DM-V1 | Two decorator straps containing five pairs of binding posts for home theater speaker connection. Includes wall plate. |
| F9008-LA-V1 | |
| F9008-WH-V1 | |


F9006-XX Single Speaker Connection Strap



F9006-WH

| PART NO. | DESCRIPTION |
|----------|---|
| F9006-BK | Decorator strap with binding posts that supports a single speaker connection. |
| F9006-BR | |
| F9006-IV | |
| F9006-LA | |
| F9006-WH | |

WP9009-XX-V1 7.1 Home Theater Wall Plate



WP9009-WH

| PART NO. | DESCRIPTION |
|--------------|--|
| WP9009-DM-V1 | Dual decorator straps with binding posts that support a 7.1 home theater solution. |
| WP9009-LA-V1 | |
| WP9009-WH-V1 | |

WP1014-WH Cable Access Strap



WP1014-WH


| PART NO. | DESCRIPTION |
|-----------|--|
| WP1014-WH | Hides cables behind the wall for a clean look and easy access. |

WP1011-XX HDMI 2-Port Strap



WP1011-WH

| PART NO. | DESCRIPTION |
|-----------|--|
| WP1011-BK | Decorator strap features a High Speed HDMI w/ Ethernet connection and two additional Keystone ports. |
| WP1011-LA | |
| WP1011-WH | |



INSTALLATION AT-A-GLANCE HD CONNECTIVITY FOR FLAT PANELS

1. Install the Cable Access Strap in a single gang box behind the flat panel TV.
2. Install the HDMI 2-Port Strap in a single gang box behind the video source, such as a DVD player.
3. Connect an HDMI cable to the back of the TV.
4. Run the cable through the Cable Access Strap and behind the wall to connect to the back of the HDMI coupler.
4. Run the cable through the Cable Access Strap and behind the wall to connect to the back of the HDMI coupler.
5. Connect an HDMI cable from the video source to the front of the HDMI Strap.